

**OULEMEI**

# ЭЛЕКТРИЧЕСКИЙ ЧАЙНИК

## OLM-SHY003



### Руководство пользователя

Внимательно прочитайте и полностью разберитесь в данном руководстве по эксплуатации перед использованием продукта. Оно содержит важную информацию для вашей безопасности, а также рекомендации по эксплуатации и обслуживанию.

## ВВЕДЕНИЕ

Пожалуйста, прочитайте эту инструкцию перед использованием электрического чайника. Сохраните руководство для повседневного использования.

## ОСОБЕННОСТИ ИЗДЕЛИЯ

1. Быстрое кипячение
2. Наличие защиты от кипения без воды
3. Поворот на 360 градусов
4. Элегантный дизайн
5. Функция поддержания тепла

## РЕКОМЕНДАЦИИ ПЕРЕД ИСПОЛЬЗОВАНИЕМ

1. Убедитесь, что изделие находится в исправном состоянии.
2. Убедитесь, что номинальные параметры изделия соответствуют требованиям национальной электросети.
3. Изделие работает только тогда, когда кувшин чайника установлен на подставку.
4. Очистите кувшин чайника перед использованием.
5. Не наливайте воду выше максимальной отметки.
6. Рекомендуется слить первую вскипяченную воду.
7. Не кипятите воду многократно; регулярно меняйте воду для здорового образа жизни.

## СПОСОБ ПРИМЕНЕНИЯ

1. НЕ подключайте кабель питания к розетке перед наполнением, опорожнением и чисткой прибора.
2. НЕ наливайте воду ниже минимального или выше максимального объема, указанного линиями на кувшине чайника, перед кипячением. Плотно закройте крышку.
3. Если вода пролилась на прибор, протрите внешнюю поверхность кувшина чайника и подставки мягкой сухой тканью.
4. Установите подставку на сухую, горизонтальную, устойчивую и термостойкую поверхность. При установке прибора на наклонную поверхность возможно его повреждение.
5. Надежно установите кувшин чайника на подставку. Подключите кабель питания, прикрепленный к подставке, в розетку. Включите настенный выключатель.
6. Прибор издаст один звуковой сигнал, все индикаторы на дисплее загорятся на 1 секунду, и прибор перейдет в режим ожидания. На панели управления будет отображаться температура воды в кувшине чайника. Если в режиме ожидания в течение 1 минуты не поступает никаких команд, прибор отключается.

### Для кипячения воды

7. В режиме ожидания нажмите кнопку «Кипячение/Отмена». Индикатор кипячения мигнет 5 раз, зуммер издаст 3 звуковых сигнала, и начнется нагрев. Индикатор остается горящим, а на панели управления в течение всего процесса нагрева отображается текущая температура воды в кувшине чайника. Как только начнется кипение, индикатор кипячения погаснет, зуммер издаст 3 звуковых сигнала, и прибор автоматически выключится.

### Повторное кипячение воды

8. После того как вода закипела, нажатие кнопки «Кипячение/Отмена» не запустит процесс нагрева заново, если контроллер температуры определит, что вода



недостаточно остыла для необходимости нагрева. Подождите несколько минут, прежде чем нажимать кнопку «Кипячение/Отмена».

#### **Поддержание воды в тёплом состоянии**

9. В режиме ожидания нажмите кнопку «Регулировка температуры». Замигает индикатор поддержания тепла. На панели управления отобразится температура по умолчанию 45°C. При нажатии кнопки «Регулировка температуры» будут отображаться 55°C, 65°C, 75°C и 85°C. Перестаньте нажимать, когда отобразится желаемая температура. Индикатор поддержания тепла мигнёт 5 раз, зуммер издаст 3 звуковых сигнала, и начнётся нагрев. Индикатор остаётся горящим, а на панели управления в течение всего процесса нагрева отображается текущая температура воды в кувшине чайника. Когда желаемая температура достигнута, она будет поддерживаться в течение 24 часов.

#### **Кипячение воды и поддержание её в тёплом состоянии**

10. В режиме ожидания нажмите кнопку «Кипячение/Отмена», затем кнопку «Регулировка температуры». На панели управления отобразится температура по умолчанию 45°C. При нажатии кнопки «Регулировка температуры» будут отображаться 55°C, 65°C, 75°C и 85°C. Перестаньте нажимать, когда отобразится желаемая температура. Индикатор кипячения и индикатор поддержания тепла мигают 5 раз, зуммер издаёт 3 звуковых сигнала, и начинается нагрев. Оба индикатора остаются горящими, а на панели управления в течение всего процесса нагрева отображается текущая температура воды в кувшине чайника.

11. Как только начинается кипение, индикатор кипячения гаснет, а индикатор поддержания тепла продолжает гореть, зуммер издаёт 3 звуковых сигнала, и температура снижается до желаемой. После достижения желаемой температуры она будет поддерживаться в течение 24 часов.

#### **Отмена кипячения/нагрева**

12. Процесс нагрева можно прервать в любой момент, подняв кувшин чайника с подставки. Однако это НЕ рекомендуется. Вам следует:

**Нажать кнопку «Кипячение/Отмена», выключить настенный выключатель и отключить кабель питания от розетки.**

## **ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ**

|                        |              |
|------------------------|--------------|
| Модель                 | OLM-SHY003   |
| Номинальное напряжение | 220-240В~    |
| Номинальная мощность   | 1500-1800 Вт |
| Частота                | 50-60 Гц     |

## ОБЩИЕ МЕРЫ ПРЕДОСТОРОЖНОСТИ

1. Данное изделие предназначено только для домашнего использования.
  2. Перед использованием изделия необходимо проверить наличие заземления в электросети.
  3. Перед использованием изделия убедитесь, что параметры электропитания (220–240 В~, 50–60 Гц) соответствуют местной электросети.
  4. Используйте изделие только при условии, что номинальное напряжение отличается от фактического напряжения в розетке не более чем на 10%.
  5. Если шнур питания изделия повреждён, пользователь должен обратиться в сервисный центр для его замены.
  6. Не наливайте воду, пока кувшин чайника установлен на подставку. Убедитесь, что подставка сухая.
  7. Не оставляйте чайник без присмотра во время работы.
  8. Храните изделие в недоступном для детей месте, чтобы избежать причинения им вреда.
  9. Держите изделие подальше от других электронных приборов.
  10. Когда пользователь включает изделие, крышка должна быть закрыта, а люди должны находиться на расстоянии. НЕ ПРИКАСАЙТЕСЬ К КОРПУСУ во время работы или после закипания воды.
  11. Всегда поддерживайте шнур питания, вилку и подставку в сухом и чистом состоянии.
  12. Не размещайте шнур питания рядом с источником тепла.
  13. Не включайте питание, если в чайнике нет воды; не включайте его во время чистки или если кто-либо выполняет операции с ним.
  14. Данное изделие предназначено для кипячения чистой воды. Не заливайте в него никакие химические жидкости, иначе это может привести к повреждению.
  15. Не ремонтируйте изделие самостоятельно.
  16. Каждое изделие имеет собственную подставку; не используйте данное изделие с другой подставкой. Не используйте другие запасные части, если их совместимость не подтверждена.
- Внимание: поверхность нагревательного элемента может оставаться горячей после использования.
17. Данным прибором могут пользоваться дети в возрасте от 8 лет и старше, если они находятся под наблюдением или проинструктированы о безопасном использовании прибора и понимают связанные с этим риски.
  18. Чистка и техническое обслуживание не должны выполняться детьми, за исключением случаев, когда они старше 8 лет и находятся под строгим наблюдением.
  19. Храните прибор и его шнур в недоступном для детей младше 8 лет месте.
  20. За детьми необходимо присматривать, чтобы они не играли с прибором.
  21. Прибор следует чистить после использования; он не предназначен для погружения в воду при чистке.

## УХОД И ЧИСТКА

### Чистка

1. Перед чисткой прибора всегда отключайте вилку от сети!
2. Внешнюю поверхность прибора при необходимости следует протирать слегка влажной тканью без моющих средств.
3. Никогда не заливайте в чайник чистящие средства. Это сделает эксплуатацию небезопасной и приведёт к повреждению устройства.

### Удаление накипи

1. Чайник следует регулярно очищать от накипи.
2. Для чистки используйте специальное средство от накипи.
3. После этого промойте чайник чистой водой.



Эта маркировка указывает, что на территории всей страны данное изделие нельзя утилизировать вместе с другими бытовыми отходами. Чтобы предотвратить возможный вред для окружающей среды или здоровья человека от неконтролируемой утилизации отходов, ответственно сдавайте его на переработку для обеспечения устойчивого повторного использования материальных ресурсов.

**Производитель:** Guangdong Oulemei Import and Export Co., Ltd.

**Адрес:** комната 301, № 2, 3-я улица Шафэн, район Байюнь, Гуанчжоу (зоны C318, C320, C322 в зале C)

**Официальный сайт торгового центра:** [www.oulemei.top](http://www.oulemei.top).

**OULEMEI**

# **ELECTRIC KETTLE**

**OLM-SHY003**



## **USER MANUAL**

Read and understand this instruction manual thoroughly before using the product. It contains important information for your safety as well as operating and maintenance advice

## INTRODUCTION

Please read this instruction before using this electric kettle. Keep this manual for daily reference.

## PRODUCT FEATURES

1. Fast boiling
2. With dry boil protection device
3. 360 degree rotation
4. With elegant design
5. Keep warm function

## GUIDELINES BEFORE USING

1. Please check that the product is in good condition.
2. Please check that the product rating meets the national power supply requirement.
3. The product can only function when the jug kettle is placed on the base.
4. Clean the jug kettle before use.
5. Do not put water above the maximum line.
6. It is suggested to pour away the first boiled water.
7. Do not reboil the water many times; regularly change the water for a healthy life.

## METHOD OF USE

1. DO NOT plug the power cable into the wall socket before filling, emptying, and cleaning the appliance.
2. DO NOT fill water lower than the minimum volume or higher than the maximum volume as indicated by the lines drawn on the kettle jug before boiling. Close the lid tightly.
3. Wipe the exterior of the kettle jug and base using a soft, dry cloth if water has spilled onto the appliance.
4. Place the base on a dry, horizontal, stable, and heat-resistant surface. Damage may occur if the appliance is placed on an incline or decline.
5. Place the kettle jug onto the base securely. Plug the power cable attached to the base into the wall socket. Switch the wall switch ON.
6. The appliance will beep once, all display lights will illuminate for 1 second, and the appliance will enter Standby mode. The control panel will display the temperature of the water in the kettle jug. After 1 minute in Standby mode with no input, the appliance will shut down.

### To Boil water

7. In Standby mode, press the “Boil/Cancel” button. The Boil Indicator Light flashes 5 times, the buzzer sounds 3 times as heating commences. The light remains illuminated, and the control panel displays the current temperature of the water in the kettle jug throughout the heating process.

Once boiling begins, the Boil Indicator Light stops illuminating, the buzzer sounds 3 times, and the appliance switches off automatically.

### To Re-boil water

8. Once the water has boiled, pressing the “Boil/Cancel” button will not restart the heating process if the temperature sensing controller determines that the temperature of the water is not cool enough to require heating. Wait a few minutes before pressing the “Boil/Cancel” button.

### To Keep water Warm

9. In Standby mode, press the “Temperature Adjustment” button. The Keep Warm Light flashes. The Control Panel displays the default temperature of 45°C. Pressing the “Temperature Adjustment” button will display 55°C, 65°C, 75°C and 85°C. Stop pressing when the desired temperature is displayed. The Keep Warm Light flashes 5 times, the buzzer sounds 3 times as heating commences. The light remains illuminated and the Control Panel displays the current temperature of the water in the Kettle Jug throughout the heating process. Once the desired temperature is reached, the temperature will be maintained for 24 hours.

#### **To Boil water and Keep water Warm**

10. In Standby mode, press the “Boil/Cancel” button followed by the “Temperature Adjustment” button. The Control Panel displays the default temperature of 45°C. Pressing the “Temperature Adjustment” button will display 55°C, 65°C, 75°C and 85°C. Stop pressing when the desired temperature is displayed. Both the Boil Indicator Light & the Keep Warm Light flash 5 times, and the buzzer sounds 3 times as heating commences. Both lights remain illuminated and the Control Panel displays the current temperature of the water in the Kettle Jug throughout the heating process.

11. Once boiling begins, the Boil Indicator Light stops illuminating while the Keep Warm Light remains illuminated, the buzzer sounds 3 times and the temperature will decrease to the desired temperature. Once the desired temperature is reached, the temperature will be maintained for 24 hours.

#### **To cancel boiling/heating**

12. The heating process can be terminated at any time by lifting the Kettle Jug away from the Base. However, this is NOT recommended. You should:

**Press the “Boil/Cancel” button, switch the wall switch OFF and unplug the power cable from the wall socket.**

## **SPECIFICATIONS**

|               |             |
|---------------|-------------|
| Model         | OLM-SHY003  |
| Rated Voltage | 220-240V~   |
| Rated Wattage | 1500W-1800W |
| Frequency     | 50-60Hz     |

## **GENERAL SAFETY PRECAUTIONS**

1. This product is for household use only.
2. Before using this product, the grounding device needs to be checked for the power supply.
3. Before using this product, please confirm that the power supply (220-240V~ 50-60Hz) is the same as the local power supply.
4. Please use the product only when the rated voltage is within 10% of the actual outlet voltage.
5. If the product's power cord is damaged, the user should contact the factory to replace it.
6. Do not fill the water while the kettle jug is placed on the base. Please make sure the base is dry.
7. Do not leave the kettle unattended while it is operating.
8. Keep this product away from children to avoid any harm to them.
9. Please keep this product away from other electronic products.
10. When the user turns on this product, the lid should be closed and people should stay away from it. **DO NOT TOUCH ITS BODY** while it is working or after the water has boiled.
11. Always keep the power cord, plug, and base dry and clean.
12. Do not place the power cord near a heat source.

13. Do not turn on the power when there is no water inside the kettle; do not turn it on while it is being cleaned or while anyone is operating it.
14. This product is for boiling plain water. Do not put any other chemical liquid in it, otherwise damage may occur.
15. Do not repair the product yourself.
16. Each product has its own base; do not use this product with another base. Do not use other spare parts unless they are confirmed to be compatible.
- Beware: the heating element surface is subject to residual heat after use.
17. This appliance can be used by children aged 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
18. Cleaning and user maintenance shall not be performed by children unless they are older than 8 and under close supervision.
19. Keep the appliance and its cord out of reach of children aged less than 8 years.
20. Children should be supervised to ensure that they do not play with the appliance.
21. The appliance should normally be cleaned after use and is not intended to be immersed in water for cleaning.

## CARE AND CLEANING

### Cleaning

1. Always remove the plug from the mains supply before cleaning the appliance!
2. The exterior of the machine should be cleaned, if necessary, with a slightly damp cloth without additives.
3. Never put cleaning detergents into the kettle. This will make the operation unsafe and damage the unit.

### Descaling

1. The kettle should be descaled regularly.
2. For cleaning, use a special descaling agent.
3. After that, wash the kettle with clean water.



This marking indicates that this product should not be disposed of with other household wastes throughout the nation. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.

Guangdong Oulemei Import and Export Co., Ltd

301, No. 2 Shafengsan Road, Baiyun District, Guangzhou (location:C318 C320 C322area)

[www.oulemei.top](http://www.oulemei.top).